

To install Tactical Rail:

Unload firearm and all other proper gun safety rules

Remove slide assembly



Next, Attach Tactical Rail to dust cove (make sure the thicker end of Tactical Rail is at the front of the dust cover) Use an elastic (good) or a clamp (best).



Next, center punch for the drill.



Next, drill the hole. Use a #29 drill (.136) For this frame we did use the elastic and a cordless hand drill. Cordless drill, good. Drill press or mill best



Next, tap the hole. Use an 8-32 tap.



Next, install screw and Tactical Rail.



Next, you must grind/file down the screw on the inside of the dust cove. This is where the recoil spring moves back and forth, if you do not grind/file the screw down, it will jam the slide.





Next, remove Tactical Rail and finish using desired method. Then reassemble Tactical Rail using a tread locking liquid.

